



Model No.	Switching Position		
BTG-DS-51	ON	NONE	ON
BTG-DS-52	ON	OFF	ON
BTG-DS-53	ON	NONE	(ON)
BTG-DS-54	(ON)	NONE	(ON)
Term. Comm.	2-3 5-6	OPEN	2-1 5-4

Schematic

