





























## Tact Switches

<b>B17300</b> TACT SWITCH 12V 0.05A   	<b>B1737A X X (FOR B1735~B1738)</b> <ul style="list-style-type: none"> <li>CAP COLOR <ul style="list-style-type: none"> <li>A:RED D:ORANGE</li> <li>B:GREEN E:IVORY</li> <li>C:BLACK F:GRAY</li> </ul> </li>   <li>HOUSING COLOR <ul style="list-style-type: none"> <li>A : LIGHT GRAY</li> <li>B : BLACK</li> </ul> </li> </ul>
<b>B17310</b> TACT SWITCH 12V 0.05A   	<b>B17335</b> TACT SWITCH 12V 0.05A  
<b>B17312</b> TACT SWITCH 12V 0.05A   	<b>B17340A /B/C/D/E</b> TACT SWITCH OPEN AND CLOSE TYPE <b>B17341A /B/C/D/E</b> TACT SWITCH OPEN TYPE    30V 0.1A LED COLOR : A: RED B: YELLOW C: GREEN D: BLUE E: WHITE
<b>B17320</b> TACT SWITCH 12V 0.05A   	<b>B17345A /B/C/D/E</b> TACT SWITCH    12V 0.05A LED COLOR : A: RED B: YELLOW C: GREEN D: BLUE E: WHITE
<b>B17322</b> TACT SWITCH 12V 0.05A   	<b>B1735</b> TACT SWITCH 12V 0.05A   
<b>B17324</b> TACT SWITCH 12V 0.05A   	<b>B1736</b> TACT SWITCH 12V 0.05A   
<b>B17326</b> TACT SWITCH 12V 0.05A   	<b>B1737A /B/C/D/E</b> ILLUMINATED TACT SWITCH 12V 0.05A    LED COLOR: A: RED B: YELLOW C: GREEN D: BLUE E: WHITE
<b>B17328</b> TACT SWITCH 12V 0.05A   	<b>B1738A /B/C/D/E</b> ILLUMINATED TACT SWITCH 12V 0.05A    LED COLOR: A: RED B: YELLOW C: GREEN D: BLUE E: WHITE
<b>B17330</b> TACT SWITCH 12V 0.05A  