


# enerpad®

BACKUP BATTERY

## Product Overview



Light Indication	Status
Light on	Show the battery capacity
Flashing	Portable power is charging Low battery capacity warning(1 light flashing)
Light off	Standby / In charging / No power

## Features

- Use 1st tier components to ensure product quality
- Innovative with Double-Protection safety technology
- Comply to international safety approvals
- 5V/2.1A max for USB output
- Compact and light weight design for portability and easy to fit into your pocket or bag
- User friendly, plug and play operation without Power On/Off the unit
- Suitable for almost all kind of digital devices with USB port
- 4 LED lights to indicate battery power level

## Caution

1. Always use the Micro USB cable included in the package and High-efficiency AC USB adapter to charge this power bank.
2. Do not expose the power bank to rain or moisture.
3. Never try to open the case of the power bank or attempt your own repairs.
4. Please avoid falling heavy pressure or strong impact to the power bank.
5. Keep away from high temperature and high humidity.
6. The product is not intended to use by young children without any supervising.
7. Do not install metal parts to the power bank.

## Package Contents

Power Pack (FN-4200D) x1  
Micro USB Cable x1  
User Guide x1  
Pouch x1


## Product Specifications

Power Bank(FN-4200D)


Function	Mobile power to charge digital devices with USB port
Battery Type	Li-Polymer Battery
Capacity	4200mAh (3.7V)
Input	DC 5V/1A
Output	DC 5V/2.1A
MTBF	More than 500 times
Dimensions	67x118x8mm
Weight	105g
Safeguards	Short circuit protection Overcurrent protection Overcharging protection Temperature protection

## User's Manual

### Charging Power Bank



### Charging your device



## Ideal for



iPod and iPhone are trademarks of Apple Inc.  
Galaxy is a registered trademark of Samsung Corporation.



*Do not crush, puncture, incinerate or short circuit.*

## INTERNATIONAL PATENTS - DESIGNS & TRADEMARKS REGISTERED

enerpad logo is a registered trademark of samya Technology Co., Ltd.

© 2011 Samya. All rights reserved.  
Samya trademark and other symbol that contain text of Samya belong to and are owned by Samya Technology Co., Ltd.



**Samya Technology Co., Ltd.**  
No.61, Ln. 770, Guangfu Rd.,  
Bade City, Taoyuan County 334,  
Taiwan (R.O.C.)  
Phone:+886-3-2181555  
Fax:+886-3-3756877  
E-Mail:service@samyatech.com  
http://www.enerpad.com.tw

# 保固證書

## Warranty Certificate

(請務必妥善保存，若遺失恕不補發)  
(Be sure to keep it safely without reissue)

產品型號 Product	
保固期間 Warranty period	購買日起一年 One year from the date of purchase
購買日期 Date of Purchase	年 / 月 / 日 (Year) / (Month) / (Day)
客戶 Client	姓名 Name
	電話 Phone
	地址 Address
經銷商店章 Dealership chapter	

1. 產品本身自購買日起，正常使用下保固一年。
2. 在下列情況時，雖在有效保證期間，恕不免費維護更新。
  - (1) 因天災地變、未按正常使用所導致故障或損壞者。
  - (2) 購買後的運送、保存不當等造成的破、損壞。
  - (3) 特殊環境不保證，如過於潮濕、酸鹼值過高等容易腐蝕地區。
  - (4) 購買發票遺失或無法辨識購買日期者。

1. One year warranty state from the purchase date of product itself under normal usage.
2. Following exceptions of free maintenance and updates during warranty period.

- (1) Due to natural disaster that caused damage.
- (2) Causes broken, damaged when delivery, or in improper preservation.
- (3) Not guarantee special circumstances, such as too wet, too high pH or susceptible to corrosion areas.
- (4) Lost of purchase invoices, or unreadable invoice date / numbers.