How the JamGuard works:



There has been a sharp increase in motor theft and theft of valuables from vehicles due to **remote jamming**. This recent trend of jamming the remote locking of cars is very common. When a person leaves their car, criminals activate their jammers which prevent the person's remote signal from reaching their car and locking the doors. As the individual walks away, thinking their car is locked, the thieves have easy access to the vehicle to steal laptops, backpacks, wallets, sunglasses and luggage.

The *JamGuard* is tailor made for the individual car owner and helps detect when criminals are attempting to jam your car remote locking system and deactivate your vehicle alarm from inside your car

JamGuard compliments your car security system.

The unit connects directly to the car battery in the bonnet and a siren alerts you when someone is trying to block or jam your vehicle's locking system. The system automatically arms itself once the vehicle is turned off.

Please note that our devices do not prevent the jamming signal – they just detect it and set off an alarm to warn you!

Benefits:

- You are immediately alerted when someone is trying to prevent you from locking your car.
- The unit is small, unobtrusive and connects directly to your car battery.
- The *JamGuard* automatically turns on when your vehicle is parked.
- The siren is loud enough to alert you once you are outside your vehicle.

For more information please visit our website:

www.remotejamming.co.za