



* For 5V , please connects with wires directly.
 For 12V , please series connects with the resistance of 1K($\geq 1/4$ W).
 For 24V ,please series connects with the resistance of 2K($\geq 1/2$ W).



NOTE: when you don't use enbl ports, no need to connect enbl ports

旧底图号	
底图总号	
日期	签名

				BREAK+2722		CHANGZHOU WANTAI ELECTRICAL APPLIANCE CO.,LTD WWW.WANTMOTOR.COM		
更改标记	更改单号	签名	日期			等级标记	重量	比例
设计	LEO		2016.4.8					
审核								
工艺								
更新	LEO		2017.11.21					
标准化								
批准								
						1	共 张	