


Milliohm, Rccb 3 Phase, Motor



3 PHASE & MOTOR ROTATION TESTER

Model : RT-608

- * 2 in 1, 3 phase rotation tester & combine with motor rotation tester.
- * Power supply : DC 9V.
- * Structure : Electronic (not mechanical).

RCCB CHECKER

Model : RCB-110V, 100~120 ACV, 50/60 Hz.

Model : RCB-220V, 200~240 ACV, 50/60 Hz.

- * Checking the power socket pin assignment.
- * Residual current circuit breaker test.
- * Rated tripping current setting 10 mA, 30 mA, 100 mA, 300 mA and 500 mA.



LINE FREQUENCY MONITOR

Model : LF-423

- * 0.5 to 500 Hz (x 0.01 Hz, < 100 Hz)
- * Input voltage : 5 to 250 ACV.
- * Check frequency to DC to AC converter, mobile & portable generator, power line.

3 PHASE ROTATION TESTER

Model : RT-606

- * 3 phase rotation detector.
- * Input : 100 - 660 V AC.
45 to 70 Hz.
- * Power supply : None.
- * Structure : Electronic



MILLIOHM METER

Model : MO-2002 (AC 110V)

Model : MO-2002 (AC 220V/AC 230V)

- * 20 mΩ/200 mΩ/2 Ω/20 Ω/200 Ω/2 KΩ/20 KΩ
- * HI / LO warning setup.
- * Large red LED display, 20.4 mm digit height.
- * 4 terminal input, high accuracy.
- * 4 wires with 2 Kelvin clips included.
- * Bench type, professional.
- * Power : AC 110V or AC 220 V/AC230 V.



MILLIOHM METER

Model : MO-2001 (AC 110V)

Model : MO-2001 (AC 220V/AC 230V)

- * 200 mΩ/2000 mΩ/20 Ω/200 Ω/2000 Ω.
- * 4 terminal input, high accuracy.
- * Size : 160 x 120 x 85 mm.
- * 4 wire with 2 kelvin clips, KV-05 is included.
- * Optional soft carrying case, CA-3K.
- * Power : AC 110V or AC 220 V/AC230 V.



EARTH RESISTANCE TESTER

Model : ET-3000

- * Earth Resistance :
19.99/199.9/1999 ohm.
- * Earth voltage : 0 - 199.9 V.
- * Power supply :
1.5 V UM3 (AA) x 6 PCs.
- * Soft carrying case, CA-3K is included.
- * Size : 160 x 120 x 85 mm.