




COMFORTABLE



# UM4 OR "AAA" CELL BATTERY HOLDER


BH411A  
BH411D **FOR ONE "AAA" CELL**  
BH411P




BH411-1A  
BH411-1D **FOR ONE "AAA" CELL**  
BH411-1P




BH411-2A  
BH411-2D **FOR ONE "AAA" CELL**  
BH411-2P




BH421A  
BH421B **FOR TWO "AAA" CELLS**  
BH421D  
BH421P



BH421-1A  
BH421-1B **FOR TWO "AAA" CELLS**  
BH421-1D  
BH421-1P




BH421-2A  
BH421-2D **FOR TWO "AAA" CELLS**



BH421-3A  
BH421-3B **FOR TWO "AAA" CELLS**  
BH421-3D  
BH421-3P



BH422A  
BH422D **FOR TWO "AAA" CELLS**



BH425A  
BH425D **FOR TWO "AAA" CELLS**  
BH425P




BH431A  
BH431B **FOR THREE "AAA" CELLS**  
BH431D

BH431-1A  
BH431-1B **FOR THREE "AAA" CELLS**  
BH431-1D

BH441A  
BH441B **FOR FOUR "AAA" CELLS**  
BH441D

BH431P



BH431-1P




BH441P




BH441-2A  
BH441-2B  
BH441-2D  
BH441-2P

FOR FOUR "AAA" CELLS




BH443A  
BH443B  
BH443D

FOR FOUR "AAA" CELLS




BH443-1A  
BH443-1B  
BH443-1D

FOR FOUR "AAA" CELLS




BH463A  
BH463B  
BH463D

FOR SIX "AAA" CELLS



BH482A  
BH482B  
BH482D

FOR EIGHT "AAA" CELLS



BH483A  
BH483B  
BH483D

FOR EIGHT "AAA" CELLS

