

# ANALOGUE PLUG-IN TIMER MTD3 (24 HOUR)

## INSTRUCTIONS FOR USE

### To Set the Time

Rotate the dial clockwise until the current time is lined-up with the arrow on the dial face. The hours are marked around the edge of the dial in 24 hour format.

Each marker between the hour numbers represents 15 minutes.

### To Set the Timer

The timer is triggered by the black push down / pull out segments located around the dial. Each segment represents 15 minutes.

#### Example:

One segment is pushed down at number 16. The timer will switch the chosen appliance on at 16:00 (4:00 pm) and switch off at 16:15 (4:15 pm).

The timer will permit up to 96 on/off programs in one 24-hour period.

To select a segment to the 'switch on' position push down the chosen segment by using a ballpoint pen, small screwdriver or other similar implement.

To de-select a segment pull out.

### To operate

- After setting the timer to the desired on/off programs, plug the timer into a mains wall socket. Make sure the socket is switched off.
- Plug in the lamp or appliance you wish the timer to control.
- Turn the chosen lamp or appliance 'on'. Switch on the wall socket.

Note: The timer will not work if the lamp or appliance is switched 'off'.  
Ensure the current time is set correctly on the timer dial.

For Lighting & appliances up to 16 Amps 220  
~ 240V AC ~ 50 Hz  
Do not overload