

JYE Tech Ltd. - www.jyetech.com -

tool provided.

pin.

corresponding pin on and align pads. main PCB.

E. Maintain BOB upright F. Finish the rest pins. and fix it by melting the solder.

49 2.3*8mm, self tapping


50 Shielding wire, 8cm

Screw

Wire

been installed on

hoard.



JYE Tech Ltd. - www.jyetech.com -